

CRICUT

- 1) Download and unzip Cricut folder;
- 2) Open Design Space and login;
- 3) Hit (+) New Project;
- 4) Hit Upload > Upload Image and browse your Cricut PNG folder > Open;
- 5) Select image type Complex > Continue > Continue > Print then Cut Image > Upload;
- 6) Select uploaded Image > Insert Images;
- 7) Edit the file size W (width) at the top to 6.75 "OR H (height) to 9,25"(make sure the padlock is locked) hit enter;
- 8) Hit Make it > Continue > Send to Printer (Add Bleed for colored borders stickers or No Bleed for white borders stickers) > Print;
- 9) Set cutting adjustment accordingly with your sticker paper;
- 10) Place the printed page on your cutting mat and load into Cricut;
- 11) Hit the flashing button GO and Ready!

INDIVIDUAL QUARTERS - Mix and Match

- 1) Download and unzip Singles folder;
- 2) Follow the steps 3 to 6 to upload each individual single PNG;
- 3) Select the 4 quarters (or 2 half pages) uploaded from the SINGLES folder (or duplicate any later) > Insert Images;
- 4) Edit each file size W (width) at the top to 3.25 "(make sure the padlock is locked) hit enter - don't worry if at this stage they're overlapping;
- 5) Follow the steps 8 to 11 above.



CUTTING INSTRUCTIONS

SILHOUETTE

- 1) Download and unzip Silhouette folder;
- 2) Open the Silhouette Studio;
- 3) Open .studio file and send to print;
- 4) Hit Send and set cutting adjustment accordingly with your sticker paper (red line - kiss cut and blue line - cut through);
- 5) Place the printed page on your cutting mat and load into Silhouette;
- 6) Hit Send again on the bottom of the page and Ready!

INDIVIDUAL QUARTERS or HALF PAGE - Mix and Match

- 1) Download and unzip Singles folder;
- 2) Open the single page .studio file in Silhouette Studio;
- 3) Choose and open the 4 individual (or 2 half pages) single PNG you want;
- 4) Copy and Paste inside each of the Single Page boxes (make sure there's no red lines overlapping the blue lines);
- 5) Follow the steps 3 to 6 above;

